

TOP COVER D120

399-691

Descrizione completa:

TOP COVER D120

Pezzi presenti all'interno del kit (vedi immagine) :



	D60R [FX]	D75R	D120R	D140R [FX]	D160R
1	Cover (left or right)			INC40-67023	
2	Cover cutter head			KIT-1027	
3	Top cover	399-690	399-216	399-691	399-692
				INC40-67014	399-693
4	Keyboard + LCD and Keypad				
4	Stand	399-050*	399-250	399-083	399-783
5	KIT stand (casters + screws + tools)			INC40-67024	
6	Basket	399-070*	399-360	399-120	399-720*
4+6	Stand + Basket	399-075*			399-680

* = Optional

www.3esestore.it



		D60R (FX)	D75R	D120R	D140R (FX)	D160R
1	Cover (left or right)				INC40-67025	
2	Cover cutter head				KIT-1027	
3	Top cover	399-690	399-216	399-691	399-692	399-693
	Keyboard + LCD and Keypad				INC40-67014	
4	Stand	399-050*	399-250	399-085	399-785	399-685
5	KIT stand (casters + screws + tools)				INC40-67024	
6	Basket	399-070*	399-360	399-120	399-720*	399-680
4+6	Stand + Basket	399-075*				

* = Optional

www.3esestore.it