

TOP COVER D140

399-692

Descrizione
completa:

TOP COVER D140

Pezzi presenti all'interno del kit (vedi immagine) :



	D60R [FX]	D75R	D120R	D140R [FX]	D160R
1	INC40-67033				
2	KIT-1027				
3	399-690	399-216	399-691	399-692	399-693
	INC40-67024				
4	399-050*	399-250	399-065	399-785	399-685
5	INC40-67024				
6	399-070*	399-360	399-120	399-720*	399-680
4+6	399-075*				

* = Optional

www.3essestore.it



		D60R (FX)	D75R	D120R	D140R (FX)	D160R
1	Cover (left or right)	1NC40-67023				
2	Cover cutter head	KIT-1027				
3	Top cover	399-690	399-216	399-691	399-692	399-693
	Keyboard + LCD and Keypad	1NC40-67014				
4	Stand	399-050*	399-250	399-085	399-785	399-685
5	KIT stand (casters + screws + tools)	1NC40-67024				
6	Basket	399-070*	399-360	399-120	399-720*	399-680
4+6	Stand + Basket	399-075*				

* = Optional

www.3essestore.it